



SYSTEM
SOFTWARE K

KIP Windows Universal Driver

Installation & User Guide

KIP Windows Universal Driver Installation & User Guide

Contents

1	Introduction	3
2	WPD Loaded Locally.....	2
	Installation and Setup (Automatic).....	2
3	Installing the Universal Windows Driver Manually	4
4	Uninstalling the Windows Driver – Automatic	9
5	Printing Preferences.....	13
6	Printing Preferences – Main Screen.....	14
7	Driver Use	24
	7.1 Using the Driver from Adobe - Example	24
	7.2 Using the Driver from AutoCAD - Example	26

1 Introduction

The new generation KIP System K Windows Driver® is Microsoft WHQL certified, meeting exact standards of reliability and quality. The functional and intuitive graphic user interface and expanded features provides the user with a wide range of standard and special functions when printing from Windows based applications

The Version 4 Windows driver is designed for local installation in the absence of a shared printer environment for ease of installation and to improve the user experience.

The KIP System K Windows Driver® can be used with the entire range of KIP Printers from any Windows based application for both Color and B&W print applications.

- 2-way communication with KIP systems
- Displays current media information and real time system status
- Label documents with username, job number and data tracking information
- Job accounting and data tracking information

1.1.1 Requirements:

The KIP Windows driver for KIP System K is WHQL certified for

- Windows 10 64 bit
- Windows 11
- Windows Server 2016
- Windows Server 2019
- Windows Server 2022

NOTE:

Microsoft .Net Framework 4.8 is required on all operating systems to be included in the driver package (distributable).

1.1.2 Supported Operating Systems


- Windows 10 64 Bit
- Windows 11
- Windows Server 2016
- Windows Server 2019
- Windows Server 2022

KIP Windows Universal Driver Installation & User Guide



2 WPD Loaded Locally

Installation and Setup (Automatic)

The Following section describes the Installation of the KIP System K Windows Driver® Please follow the Step-by-step procedure for correct installation.


Step	Action	Illustration
1.	<p>Open the Universal Windows Driver folder and double click the icon.</p> <p>Please Note: This driver is designed to be installed locally at each workstation.</p>	
2.	<p>If asked to authorize select "Yes".</p>	
3.	<p>The installer will search the network for System K printers. All discovered KIP System K printers will be displayed in the "Discovered IP Address" dropdown. Once the IP is selected from "Discovered IP Address" dropdown menu, the other fields will populate automatically. Click Begin to commence installation.</p> <p>Please Note: The Universal WPD only installs in postscript mode. No GL mode is available.</p>	

KIP Windows Universal Driver Installation & User Guide




Step	Action	Illustration
4.	<p>Once Complete the driver installation will display Success!</p> <p>A message to reboot may also be displayed.</p>	
5.	<p>When Done Installing select the “Quit” button to Close the installation.</p>	
6.	<p>REBOOT THE WORKSTATION IF PROMPTED – THIS STEP MUST BE DONE!</p>	
7.	<p>The Driver is now installed and should be present in the Printers & Scanners screen</p>	

3 Installing the Universal Windows Driver Manually




The following section describes the manual installation of the KIP System K Windows Universal Driver®. Please follow the Step-by-step procedure for correct installation

Step	Action	Illustration
1.	<p>There are a couple of ways to start:</p> <ol style="list-style-type: none"> 1. Type Printers and Scanners into the search bar. Select the Printers and scanners option. 2. Open Control Panel and select Devices and Printers. <p>The following steps are using Control Panel.</p>	<p>1. </p> <p>2. </p>
2.	Select Add a Printer	
3.	Select "The printer that I want is not listed".	




KIP Windows Universal Driver Installation & User Guide

Step	Action	Illustration
4.	Select “Add a local printer or network printer with manual settings”. Select Next	
5.	Select “Create a new port”. Set the “Type of port” to Standard TCP/IP Port Select Next	
6.	When the Type a printer hostname or IP address window opens enter the KIP Printer’s Hostname or IP Address and select Next.	




KIP Windows Universal Driver Installation & User Guide

Step	Action	Illustration
7.	Select the Have Disk Button Select Next	
8.	Browse to the location of the KIP Windows Universal Driver Folder. Open the folder and then open the "DRIVER" folder.	
9.	Select the KipV4Win.inf and select Open	

KIP Windows Universal Driver Installation & User Guide




Step	Action	Illustration
10.	This will add the Driver to the Manufacturer list. Scroll down and select KIP from the list. And then scroll down and select the V4 Driver.	
11.	Name the Printer and select Next	
12.	Select if the printer is to be shared and select Next. Note: a local install of this driver is strongly recommended	

KIP Windows Universal Driver Installation & User Guide




Step	Action	Illustration
13.	Print a test page if desired and then select Finish	
14.	Confirm printer instance has been added to Printers and Scanners.	
15.	PLEASE NOTE	<p>If installing the KIP V4 Windows Driver manually and Sleep modes are going to be used it will be necessary to disable SNMP at the Port level. If this is not done the Driver will not be able to wake the printer if in sleep mode.</p> 

4 Uninstalling the Windows Driver – Automatic




The following section describes the automatic Uninstallation of the KIP System K Windows Driver®. Please follow the Step-by-step procedure for correct uninstallation

Step	Action	Illustration
1.	Open Control Panel	
2.	Open Devices and Printers	
3.	Select the KIP Printer and right click on it. Select Remove Device.	
4.	<p>When asked “Are you sure you want to remove this device” select Yes.</p> <p>This will remove the printer instance.</p>	


KIP Windows Universal Driver Installation & User Guide

Step	Action	Illustration
5.	Next select any Printer Icon. This will allow for the Selection of Print Server Properties from the top menu.	
6.	Select the Ports Tab and scroll to the KIP Printer that was just removed. And select Delete Port.	
7.	Select OK to Delete the Printer.	


KIP Windows Universal Driver Installation & User Guide

Step	Action	Illustration
8.	Select the Drivers Tab, select the KIP V4 driver and then select Remove	
9.	Next, select “Remove driver and driver package. Select OK	
10.	Select “Yes” for the following message.	




KIP Windows Universal Driver Installation & User Guide

Step	Action	Illustration
11.	<p>Once the driver package information is collected select Delete. This will remove the Driver and its installation package from the workstation.</p> <p>Reboot the workstation if asked to do so.</p>	





5 Printing Preferences







6 Printing Preferences – Main Screen

Component	Function
<p>1. User Name</p>	<div data-bbox="906 495 1203 684" style="text-align: center;">  </div> <p>If accounting is not active (Users are not asked to login) the software will use %username% and pull the name of the person currently logged in.</p> <p>If accounting is active (Users are asked to login) the username entered will be used.</p>
<p>2. Project</p>	<div data-bbox="899 915 1206 1121" style="text-align: center;">  </div> <p>The Project field is used for accounting purposes, this can be a simple required entry box, a simple dropdown box with a selection of project names/numbers or a dropdown with a selection of project names/numbers with passwords that are required.</p>
<p>3. Department</p>	<div data-bbox="904 1335 1201 1541" style="text-align: center;">  </div> <p>The Department field is used for accounting purposes, this can be a simple required entry box, a simple dropdown box with a selection of department names or a dropdown with a selection of department names with passwords that are required.</p>





KIP Windows Universal Driver Installation & User Guide

Component	Function
4. Copies	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Allows for the selection of the number of copies to be printed.</p>
5. Page Size	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Allows for the selection of the size the document is to be printed.</p>
6. Color Mode	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Set Color Mode, Choose from Black and White (1bit), Gray (8bit) and Color (24bit) modes for printing.</p>






KIP Windows Universal Driver Installation & User Guide

Component	Function
<p>7. Quality</p>	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Choose from default Print Quality settings:</p> <ul style="list-style-type: none"> • CAD • Graphics • Photo <p>Custom Print Quality Presets (if available)</p>
<p>8. PS Preset</p>	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Allows for the selection of a Postscript preset other than the Default.</p>
<p>9. Collation</p>	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Allows for the collation of sets. Select from Default, Off, On, Reverse and Smart Stacking.</p> <p>On – 1, 2, 3</p> <p>Reverse – 3, 2, 1</p> <p>Smart Stacking – First page always on top, regardless of paper exit (Default).</p>




KIP Windows Universal Driver Installation & User Guide

Component	Function
10. Media Type	<div style="display: flex; justify-content: space-around;">   </div> <p>Allows for the selection of available media currently loaded in the KIP Printer. Available medias will be listed in the selection window.</p>
11. Media Source	<div style="display: flex; justify-content: space-around;">   </div> <p>Select from Roll or Cut Sheet (if active and available)</p>
12. Color Adjustment	<div style="display: flex; justify-content: space-around;">   </div> <p>Brightness – Slider controls brightnes from -20 (dark) to +20 (light). Green to Red Adjust – Slider controls Gren to Red color from -20 (Green) to +20 (Red). Blue to Yellow Adjust – Slider controls Blue to Yellow colors from -20 (Blue) to +20 (Yellow).</p> <p>Note: If the the windows driver is used in Black and White mode these sliders do not affect the output.</p>
13. Mirror	<div style="display: flex; justify-content: space-around;">   </div> <p>Allows the user to Mirror the image on the output file.</p>



KIP Windows Universal Driver Installation & User Guide

Component	Function
14. Scaling	<div style="display: flex; justify-content: space-around;">   </div> <p>Allows for the selection of Pre-Configured sizes or the entry of a specific Percentage.</p>
15. Alignment	<div style="display: flex; justify-content: space-around;">   </div> <p>Choose from: Left Right or Center</p>
16. Add Margin	<div style="display: flex; justify-content: space-around;">   </div> <p>Choose from:</p> <ul style="list-style-type: none"> None: No change is made Shrink Image: Increasing the margin (Left, Right or Top, Bottom) will keep the same paper size but shrink and scale the image to fit Clip Image: Adds to the edges of the drawing but does not change its size or scale Expand Page: Drawing will keep the same image size/scale but will add white space to the page

KIP Windows Universal Driver Installation & User Guide

Component	Function
17. Remove Border	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Allows the user to enable the ability to remove any white borders.</p>
18. Stamp	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Allows for the selection of a specific stamp to be applied to all sheets printed in the job.</p>
19. Separator	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Job Separator – Job Separator prints after the entire job has finished Set Separator - Set Separator prints after each set has finished Job and Set – Separator prints after each Set/Job has finished</p>

KIP Windows Universal Driver Installation & User Guide

Component	Function
20. Exit Tray	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Allows for the selection of available finishing options, Top, Rear, Fold (if a folder is attached). Note: on the KIP 970 there is no Front option.</p>
21. Secure Print	<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Secure Print has the following options:</p> <ul style="list-style-type: none"> • None - Job is sent to the printer and prints out. • Pin - Allows for the entry of a code number (up to four digits) to be entered. If used this code will be necessary to release the files at the printer user interface. • User – When selected job will be sent with the Users name. It will be necessary for that user to login on the KIP touchscreen to release the job.
22. Show More/Show Less	<div style="display: flex; justify-content: center; gap: 20px; margin-bottom: 10px;"> <div style="border: 1px solid black; padding: 5px 15px; background-color: #cccccc;">SHOW MORE</div> <div style="border: 1px solid black; padding: 5px 15px; background-color: #cccccc;">SHOW LESS</div> </div> <p>Used to Collapse or expand the main properties window of the Driver.</p>


KIP Windows Universal Driver Installation & User Guide

Component	Function
23. Templates	<div data-bbox="883 394 1224 464" style="text-align: center; border: 1px solid black; padding: 5px; margin-bottom: 10px;"> TEMPLATES </div>  <p data-bbox="581 978 1503 1045">Allows the user to create templates that can be used at anytime to load in specific configurations.</p>
24. Printer	<div data-bbox="833 1094 1276 1268" style="text-align: center; border: 1px solid black; padding: 10px; margin-bottom: 10px;"> PRINTER KIP-860-CLASS Ready </div> <p data-bbox="581 1297 1130 1331">Displays realtime status of the KIP Printer.</p>
25. Toner	<div data-bbox="743 1381 1369 1556" style="text-align: center; border: 1px solid black; padding: 10px; margin-bottom: 10px;"> TONER  </div> <p data-bbox="581 1587 1203 1621">Displays realtime status of the remaining Toner.</p>

KIP Windows Universal Driver Installation & User Guide

Component	Function
26. Media	<div data-bbox="699 390 1409 560" data-label="Image"> </div> <p data-bbox="581 590 1490 657">Displays real time status of the available media currently loaded in the KIP Printer</p>
27. OK/Cancel	<div data-bbox="854 705 1255 793" data-label="Image"> </div> <p data-bbox="581 829 1016 909">OK - Set changed settings. Cancel - Closes out of the screen</p>
28. Options	<div data-bbox="977 957 1133 1037" data-label="Image"> </div> <p data-bbox="581 1071 1503 1184">Options - Displays available Options (see section below for explanation of Options) X – Closes window</p>

KIP Windows Universal Driver Installation & User Guide

Component	Function
<p>Options (details)</p> <ul style="list-style-type: none"> • Preferences <ul style="list-style-type: none"> a. Enable SNMP. SNMP Community: Public (can be edited) b. Save changes made by applications • Print Time Preview <ul style="list-style-type: none"> a. On – Off by default • File Output <ul style="list-style-type: none"> b. Add XML settings • Driver Version – Displays Current Driver Version • Language <p>Note: The “Enable SNMP” is on by default. This allows the KIP Windows Driver to wake the printer from sleep mode if Sleep modes are used.</p>	
<p>29. Driver Name</p>	<p style="text-align: center;">KIP Universal Printer Driver</p>

KIP Windows Universal Driver Installation & User Guide

7 Driver Use


Please note: The setting "Detect Color" that can be applied to KIP Applications does not apply to Windows drivers. For Black and White, Greyscale or Color output the output mode needs to be selected.

7.1 Using the Driver from Adobe - Example

In this example Adobe Pro X will be used.

Step	Action	Illustration
1.	Open the Adobe Application	
2.	Go to File and then to "Open" or select from the "Open a Recent File" selection.	
3.	Go to File and Select Print and choose the KIP Universal Printer Driver.	
4.	To use the available options, select the Properties button.	



KIP Windows Universal Driver Installation & User Guide

Step	Action	Illustration
5.	Once the Properties button opens make desired changes.	
6.	Select Show More for more options.	 <p>Note: see the Above section for descriptions of options.</p>
7.	Select OK	
8.	Select Print to send the File to the KIP Printer.	


7.2 Using the Driver from AutoCAD - Example

Please note: The setting "Detect Color" that can be applied to KIP Applications does not apply to Windows drivers. For Black and White, Greyscale or Color output the output mode needs to be selected.

For this example, AutoCAD 2018 was used.

Step	Action	Illustration
1.	Open the AutoCAD Application	
2.	Click on the "A" in the top Left corner. When the Drop-down window opens select Print.	
3.	Select the KIP Printer Driver From the available printers list.	
4.	To use the available options, select the Properties button.	
5.	Select the Custom properties button	

KIP Windows Universal Driver Installation & User Guide

Step	Action	Illustration
6.	Once the Properties button opens make desired changes.	
7.	Select Show More for more options.	 <p data-bbox="659 1234 1373 1268">Note: see the Above section for descriptions of options.</p>
8.	Select OK	
9.	Select Print to send the File to the KIP Printer.	